



# TH04 FLASHLIGHT INSTRUCTION MANUAL



## WARNING:

1. Do not shine directly in the eyes, the powerful LED light will damage the eyes immediately.
2. If the battery is not used for a long time, please charge and discharge it every 3 months to keep the battery in good condition.
3. It is normal to use the lights for a long time to heat up.
4. When the indicator light shows low power, please charge the battery as soon as possible.
5. Please keep the battery away from water, moisture and drop etc.
6. To avoid damage to the surface of the flashlight, please do not expose the flashlight to sunlight, water, chemicals, corrosive gases or any other oxidizing environment frequently.
7. Before use, please tear off the transparent film on the battery surface before use.

## INSTRUCTIONS FOR USE



Tail suction



Bracket mounting



Switch/charging port

① Support chamfer direction

② Align the lamp tail clamp

Push the bracket to the bottom and there will be a click

1. Press the button to turn on the strong light source, and the order of modes is (Strong Light-Medium Light-Low Light-Strobe-SOS-Off) in sequence. Any modes long press 2S to shut down.
2. The red indicator light is always on when charging, and the blue indicator light is always on when fully charged.

## PRODUCT PARAMATERS

Model	TH04	Power	5w
Charging ways	Type-C	Weight	114G
Battery	18650	Size	111*27*24mm
Mode	Strong Light-Medium Light-Low Light-Strobe-SOS-Off		

## APPLICATION SCENARIO



Camping



Mountaineering



Capture



GO fishing



Rock climbing



Cycling



Motion



Construction



Explore



Repair

# Warranty card

User name: \_\_\_\_\_

Phone number: \_\_\_\_\_

E-mail: \_\_\_\_\_

Address: \_\_\_\_\_

Other Contacts: \_\_\_\_\_

Release Date: \_\_\_\_\_